
RP 4A
RPLF 4A
1/2" - 2"



RP 4A
½"-2"

REPAIR KITS

CM is Check Module **C is Complete subassembly(s)** **R is Rubber only**
RPCM is RP first Check Module

		RP Checks Rubber Only Kit (One kit repairs one check)				
		Size				
ITEM #	Repair Kit Model Number	1/2"	3/4"	1"	1-1/4" - 1-1/2"	2"
	Ordering Code	RK4A12CMR	RK4A34CMR	RK4A1CMR	RK4A112CMR	RK4A2CMR
not shown	O-Ring Lubricant	4A-003-01	4A-004-01	4A-005-01	4A-007-01	4A-008-01
20	Check Module Seat Disc	I-9016-00				
7	Check Module O-Ring	D-4771-00	D-4743-00	D-4770-00	D-4853-00	D-4873-00
6	Cap O-Ring (for RP)	D-4880-00	D-4744-00	D-4882-00	D-4884-00	D-4885-00
		D-4881-00	D-4812-00	D-4884-00	D-4885-00	D-4888-00

		RP First Check Complete Kit (One kit repairs one check)				
		Size				
ITEM #	Repair Kit Model Number	1/2"	3/4"	1"	1-1/4" - 1-1/2"	2"
	Ordering Code	RK4A12RPCMC	RK4A34RPCMC	RK4A1RPCMC	RK4A112RPCMC	RK4A2RPCMC
not shown	O-Ring Lubricant	4A-003-03	4A-004-03	4A-005-03	4A-007-03	4A-008-03
14	Check Module S-ASSY	I-9016-00				
7	Check Module O-Ring	W-9207-05	W-9208-05	W-9209-05	W-9210-05	W-9211-05
6	Cap O-Ring (for RP)	D-4880-00	D-4744-00	D-4882-00	D-4884-00	D-4885-00
		D-4881-00	D-4812-00	D-4884-00	D-4885-00	D-4888-00

		RP Second Check Complete Kit (One kit repairs one check)				
		Size				
ITEM #	Repair Kit Model Number	1/2"	3/4"	1"	1-1/4" - 1-1/2"	2"
	Ordering Code	RK4A12CMC	RK4A34CMC	RK4A1CMC	RK4A112CMC	RK4A2CMC
not shown	O-Ring Lubricant	4A-003-02	4A-004-02	4A-005-02	4A-007-02	4A-008-02
15	Check Module S-ASSY	I-9016-00				
7	Check Module O-Ring	W-9075-05	W-9003-05	W-9074-05	W-9159-05	W-9204-05
6	Cap O-Ring (for RP)	D-4880-00	D-4744-00	D-4882-00	D-4884-00	D-4885-00
extra part*	Bonnet O-Ring (for PVB)	D-4881-00	D-4812-00	D-4884-00	D-4885-00	D-4888-00
		D-4812-00	D-4883-00	D-4887-00	D-4858-00	

*Extra part not needed for RP4A

		RP Relief Valve Rubber Kit				
		Size				
ITEM #	Repair Kit Model Number	1/2"	3/4"	1"	1-1/4" - 1-1/2"	2"
	Ordering Code	RK4A1RVR			RK4A112RVR	RK4A2RVR
not shown	O-Ring Lubricant	4A-005-04			4A-007-04	4A-008-04
10	RV Diaphragm	I-9016-00				
13	RV Bushing O-Ring	D-2632-00			D-2505-00	D-4909-00
11	RV Seat O-Ring	D-4893-00			D-4744-00	D-4904-00
29	RV Stem O-Ring	D-4892-00			D-4910-00	D-4903-00
31	RV Seat Disc	D-4891-00			D-4927-00	D-4902-00
		D-4833-00			D-4911-00	D-4912-00
		RP Relief Valve Complete Kit				
ITEM #	Repair Kit Model Number	RK4A1RVC			RK4A112RVC	RK4A2RVC
	Ordering Code	4A-005-05			4A-007-05	4A-008-05
not show	O-Ring Lubricant	I-9016-00				
10	RV Diaphragm	D-2632-00			D-2505-00	D-4909-00
13	RV Bushing O-Ring	D-4893-00			D-4744-00	D-4904-00
11	RV Seat O-Ring	D-4892-00			D-4910-00	D-4903-00
16	RV S-ASSY	W-9223-05			W-9244-05	W-9245-05
12	RV Seat	L-7894-00			L-8038-00	L-8039-00

			RP Complete Rubber Only Kit (One kit repairs one RP valve)				
			Size				
ITEM #	Repair Kit Model Number	QTY.	1/2"	3/4"	1"	1 1/4" 1 1/2"	2"
	Ordering Code		RK4A12TR	RK4A34TR	RK4A1TR	RK4A112TR	RK4A2TR
not shown	O-Ring Lubricant	2	4A-003-09	4A-004-09	4A-005-09	4A-007-09	4A-008-09
20	Check Module Seat Disc	2	I-9016-00				
7	Check Module O-Ring	2	D-4771-00	D-4743-00	D-4770-00	D-4853-00	D-4873-00
6	Cap O-Ring	2	D-4880-00	D-4744-00	D-4882-00	D-4884-00	D-4885-00
10	RV Diaphragm	1	D-4881-00	D-4812-00	D-4884-00	D-4885-00	D-4888-00
13	RV Bushing O-Ring	1	D-2632-00			D-2505-00	D-4909-00
11	RV Seat O-Ring	1	D-4893-00			D-4744-00	D-4904-00
29	RV Stem O-Ring	1	D-4892-00			D-4910-00	D-4903-00
31	RV Seat Disc	1	D-4891-00			D-4927-00	D-4902-00
			D-4833-00			D-4911-00	D-4912-00