Series 800M3


Pressure Vacuum Breaker

Sizes 1/2" and 3/4"

Repair Kits

When ordering specify Ordering Code, Kit No., and Valve Size.

ORDERING CODE	KIT NO.	SIZE
Check Kits		
LEAD FREE* 0886042	RK 800M3 CK	½", ¾"
Kit consists of: check disc assembly (disc & disc holder), bonnet O-ring and check spring.		
Vent Float Kits		
LEAD FREE* 0886041	RK 800M3 V	½", ¾"
Kit consists of: float vent disc assembly (vent float, seal & spring) and bonnet O-ring.		
Bonnet Assembly Kits		
LEAD FREE* 0886040	RK 800M3 B	½", ¾"
Kit consists of: bonnet, bonnet O-ring, vent spring, hood & hood screws.		
Rubber Part Kits		
LEAD FREE* 0886039	RK 800M3 RT	½", ¾"
Kit consists of: vent seal, check disc and bonnet O-ring.		



Series 800M2

Pressure Vacuum Breaker

Sizes 1/2" – 2"

Repair Kits

When ordering specify Ordering Code, Kit No., and Valve Size.

ORDERING CODE	KIT NO.	SIZE
Check Kits		
LEAD FREE 0886037	RK 800M2 CK	½" – 1"
LEAD FREE 0886038	RK 800M2 CK	1¼" – 2"
Kit consists of: check disc assembly (disc & holder), bonnet O-ring and check spring.		
Vent Float Kits		
LEAD FREE 0886035	RK 800M2 V	½" – 1"
LEAD FREE 0886036	RK 800M2 V	1¼" – 2"
Kit consists of: float vent disc assembly (vent float, seal & spring) and bonnet O-ring.		
Bonnet Assembly Kits		
LEAD FREE 0886033	RK 800M2 B	½" – 1"
LEAD FREE 0886034	RK 800M2 B	1¼" – 2"
Kit consists of: bonnet, bonnet O-ring, vent spring, hood & hood screws.		
Rubber Parts Kits		
LEAD FREE 0886031	RK 800M2 RT	½" – 1"
LEAD FREE 0886032	RK 800M2 RT	1¼" – 2"
Kit consists of: vent seal, check disc and bonnet O-ring.		

